



NOTES:

- ①- CONCRETE TO BE 2500 PSI
- ②- APPROACH & SIDEWALK IN DRIVE TO BE 6" THICK W/ WIRE MESH OR FIBER MESH.
- ③- 1 x 4 USED AT EXPANSION JOINTS TO BE PRESSURE TREATED.
- 4- ALL WOOD STAKES USED IN FORM WORK TO HAVE 2" OR MORE MORE OF CONCRETE COVER.
- ⑤- SIDEWALK TO BE JOINTED AT INCREMENTS TO EQUAL SIDEWALK WIDTH. NOT REQUIRED IN DRIVE.

CITY OF MASCOTTE UTILITIES DEPARTMENT

DRIVEWAY
APPROACHES

DATE:

DWG:

FIG:

R600